

**EN** Attention:

- Insert correctly (+/-).
- Do not charge, do not disassemble, do not dispose of in fire -
- They might explode!
- Do not put batteries on metallic surfaces - danger of short-circuits!
- Keep away from children - they might be swallowed up!
- Do not use following batteries at the same time: old and new,
- half full and full, different brands and capacities.
- Remove immediately from device if not in use or the
- batteries are empty.
- Dispose of defective and empty batteries properly
- (hazardous waste).
- Read the manual of your electronic device carefully.

Keep for future reference!

**DE** Achtung:

- Polaritäten (+/-) beachten!
- Batterien nicht aufladen, nicht öffnen, nicht ins Feuer werfen - Explosionsgefahr!
- Batterien nicht auf metallische Oberflächen legen - Kurzschlussgefahr!
- Von Kindern und Tieren fernhalten - Verschluckungsgefahr!
- Folgende Batterien nicht gleichzeitig verwenden: alte und neue, halbvolle und volle, verschiedene Marken und Kapazitäten.
- Unverzüglich aus dem Gerät nehmen, wenn ungenutzt oder leer.
- Defekte und leere Batterien ordnungsgemäß entsorgen (Sondermüll).
- Lesen Sie die Bedienungsanleitung Ihres Gerätes aufmerksam durch.



Anleitung sorgfältig aufbewahren!

distributed by:

***messingschlager***

Messingschlager GmbH & Co. KG  
Hassbergstr. 45 · 96148 Baunach - Germany  
info@messingschlager.com  
www.messingschlager.com

02/2025

